



# Hitachi Power Tools

## ELECTRIC TOOL PARTS LIST

### ■ TABLE TOP MITER SAW Model C12YB



C12YB



## PARTS

C12YB

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARK
1	332369	SCREW	1	
4	332258	WHEEL FLANGE	1	
5	332269	INTEGRATED BLADE FLANGE	1	
6	332275	SCREW	5	
7	332290	LEFT SAW COVER	1	
9	332295	SCREW	2	
10	332227	SPECIAL NUT	1	
11	332228	PROTECTION PIN	1	
12	332229	LEVER AND PROTECTION GROUP	1	
14	332231	SNAP RING	1	
16	332391	CARD BOX	1	
17	332398	BLADE SUPPORT GROUP	1	
18	332266	KNOB	1	
20	332238	PROTECTION SPRING	1	
22	332240	SPECIAL NUT	1	
23	332399	HANDLE SUPPORT	1	
25	332400	SCREW	4	
26	332244	RIVIGN KNIFE PLATE	1	
27	332245	SCREW	1	
28	332246	WASHER	4	
29	332247	UPPER TABLE SCREW	1	
30	332333	ELASTIC PIN	2	
31	332250	WASHER	1	
32	332251	RIVING KNIFE	1	
34	332253	WASHER	1	
35	332330	SNAP RING	1	
36	332401	COMPLETE MOTOR GROUP	1	
37	332255	LEFT HALF HANDLE	1	
38	332256	SAFETY BUTTON	1	
39	332257	SAFETY BUTTON	1	
40	332259	SPRING	1	
41	332260	RELEASE BUTTON	1	
42	332261	LEVER	1	
43	332262	SWITCH	1	
44	332263	RELEASE LEVER GROUP	1	
45	332264	SPRING	1	
46	332402	CABLE BOX	1	
47	332403	CABLE LOCKING DEVICE	1	
48	332370	SCREW	2	
49	332371	FRONT BOX COVER	1	
50	332270	RIGHT HALF HANDLE	1	
51	332271	SCREW	1	
52	332372	RUBBER PROTECTION	1	
53	332377	ELECTRIC BOX COVER	1	
54	332274	SPACER	1	
56	332374	REAR BOX COVER	1	
57	332375	SCREW	1	
61	332282	CABLE LOCKING DEVICE	1	
64	332376	ELECTRONIC CARD	1	
65	332373	CABLE	1	

## PARTS

C12YB

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARK
66	332378	TERMINAL CI AMP	1	
68	332288	KNOB	1	
70	332291	SCREW	2	
71	332379	RIGHT SAW COVER	1	
72	332349	ADDITIONAL PROTECTION	1	
75	332296	EXAGONAL NUT	2	
76	332362	UPPER PROTECTION	1	
77	332363	SCREW	1	
78	332364	KNOB	1	
79	332365	SPRING	1	
80	332366	SNAP RING	1	
81	332367	SCREW	2	
84	332368	UPPER TABLE FRONT GUIDE	1	
85	332360	BALL	1	
89	332397	CABLE	1	
93	332351	UPPER TABLE REAR GUIDE	1	
95	332352	SCREW	2	
98	332353	UPPER TABLE	1	
99	332354	SCREW	1	
100	332355	GUIDE	1	
101	332356	UPPER TABLE GUIDE	1	
102	332357	LOWER PROTECTION	1	
103	332358	SHEFT BRAKET	1	
104	332359	WING NUT	1	
105	332296	EXAGONAL NUT	2	
106	332307	WASHER	2	
107	332318	SPRING WASHER	1	
108	332329	JOINT BUSHING	1	
109	332340	JOINT RING	1	
110	332346	JOINT SPRING	1	
111	332346	RIGHT STEEL PROTECTION	1	
112	332347	SCREW	4	
113	332348	HAND LEVER	1	
114	332297	SPACER	1	
115	332298	TIE ROD	1	
116	332299	EXAGONAL NUT	2	
117	332219	ADDITIONAL LOWER PROTECTION	1	
118	332300	MITRE SAW BASE	1	
119	332301	EXAGONAL NUT	1	
120	332302	SPRING WASHER	4	
121	332303	WASHER	1	
122	332304	PLATE	1	
123	332305	ANGULAR BRACKET	1	
124	332306	WASHER	2	
125	332308	WING NUT	1	
126	332309	SPIRNG	1	
127	332310	SCREW	1	
128	332311	EXAGONAL NUT	1	
129	332312	SWIVEL SUPPORT PIN	1	
130	332313	RELEASE LEVER	1	

## PARTS

C12YB

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARK
131	332314	SLIDING PLATE	1	
132	332315	SUPPORT FOOT	4	
133	332316	SCREW	2	
134	332317	PLASTIC COVER	1	
135	332319	BASE INDEX	1	
136	332320	SCREW	1	
137	332321	SPACER	1	
138	332322	BASE EXTENSION	1	
139	332323	SWIVEL SUPPORT	1	
140	332324	TURNING TABLE COVER	1	
141	332325	SCREW	4	
142	332326	BUSHING	1	
143	332327	HEADLESS SCREW	2	
144	332328	SCREW	1	
145	332330	SNAP RING	1	
146	332331	LEFT STEEL PROTECTION	1	
147	332332	EXAGONAL NUT	4	
148	332333	ELASTIC PIN	2	
149	332334	JOINT PIN	1	
150	332335	JOINT	1	
151	332336	SCREW	1	
152	332337	JOINT SHAFT	1	
153	332338	WASHER	1	
154	332339	SCREW	1	
155	332341	SCREW	2	
156	332342	JOINT INDEX	1	
157	332343	JOINT GROUP	1	
158	332294	RELEASE LEVER BUTTON	1	
165	332344	WASHER	1	
167	332381	BRUSHES	2	
168	332382	MOTOR COVER	1	
180	332395	BRUSHES SUPPORT	1	
182	332361	COMPLETE UPPER GUIDE	1	
183	332225	ROD STOP GROUP	1	
184	332224	ALLEN KEY	1	
185	332223	ALLEN KEY	1	
186	332220	WOOD PUSHING DEVICE	1	
187	332380	SPRING BUSHING	1	